

INSTALLATION INSTRUCTIONS

NETLAG ACOUSTICAL PIPES

- 1 Determine the circumference of the pipe to be wrapped. Additional length required to accommodate thickness of material. Add 2–4 inches overlap of product onto itself. *(Note: Quilted Fiberglass side goes against the pipe)*
- 2 Utilizing standard 54" wide rolls, cut length as determined above.
- 3 After cutting piece from roll install first section on the pipe. Drape the cut piece over the pipe with equal parts of the product hanging over each side. One side is then brought up and adhered to the pipe with a foil lag (FSK) tape. The other side is then brought up, making sure to overlap the first side, and secured with FSK tape. This method allows for circumferential seams approximately every 50" to 52", and a single seam running along the bottom of the pipe.
 - Add additional wraps of tape around circumference as required to snug lagging to pipe.
 - Where specified or as required banding should be installed in addition to tape to secure lag to pipe.
- 4 Cut and install the next section in the same fashion. Each progressive section should overlap the previous section by 2 inches (+/-). Tape this seam with a 4" wide foil lag tape.
- 5 When covering an elbow the usual method is to "gore" the product (as typical in sheet metal construction).
- 6 In all cases the important element is to assure there are no gaps or leaks whatsoever.

